

Garland - Table Base Installation and Two-Piece Top Assembly

Steelcase®





If you have a problem, question, or request, call your local dealer, or Steelcase Line 1 at 888.STEELCASE (888.783.3522) for immediate action by people who want to help you.

(Outside the U.S.A. Canada, Mexico, Puerto Rico, and the U.S. Virgin Islands, call: 1.616.247.2500)
Or visit our website: www.steelcase.com


© 2002 Steelcase Inc. Grand Rapids, MI 49501 U.S.A.


IMPORTANT!

Before discarding packaging, please ensure that all parts are included. For Round Task Tables, please see exploded view of assembly on page 2.

Round Metal Base Installation

1. Determine if you want the mousehole in the up or down position, then assemble base as shown.






Page 2 of 5 Y9501757 Rev.M


Steelcase


- **2.** Carefully turn top over onto carpet or other soft, clean material.
- **3.** Locate and install base assembly.



NOTE: If using a rectangular or square top, make sure base is mounted in a diagonal orientation (see above) to top.

The drawing below shows the incorrect positioning of the base with top.







Steelcase

Panel Base Installation

- 1. Align dowels with holes in top panel.
- 2. Using holes in mounting bracket as guide, pilot drill (12) holes 1/8" (3.1mm) dia. and 1/2" (12.7mm) deep.
- 3. Install (12) screws.
- 4. Install support bracket with (5) 7/8" screws as shown.
- 5. Repeat procedure for other base assembly.







Page 4 of 5 Y9501757 Rev. M


Steelcase


Two-Piece Top Assembly

- 1. Install (3) splines into groove in one end of top section.
- 2. Slide top halves together.
- 3. Install (4) joint fasteners.
- 4. Tighten joint fasteners with punch or similar tool as shown.
- 5. Refer to preceding page to install base assemblies.









Page 5 of 5 Y9501757 Rev. M