

# Lightline® Recessed

## Installation Planning Guide

Type:


Project:

### Recessed — 2 1/2" Aperture


#### CEILING COMPATIBILITY

Mounting Data	Appropriate Ceiling Type
Exposed grid tee	G
Plaster or gyp-board <sup>1</sup>	G


<sup>1</sup>Requires flange kit. Specify option FLNG or order separately: DHSGS2 (for 2') DHSGS4 (for 4')



LAY-IN TRIP,  
9/16" or 15/16" exposed grid tee




SCREW SLOT TRIM,  
fixture to flush ceiling




PLASTER OR GYP-BOARD

#### T-BAR MOUNTING DETAIL




#### WEIGHTS & DIMENSIONS



**Key:**  
○ Standard feed location  
■ EM feed location

#### FLANGE KIT INSTALLATION

1. Cut hole in ceiling and drop power feed through aperture. Opening for G trim fixtures with DHSGS:<sup>2</sup>  
4" x 24" for 2'  
4" x 48" for 4'



<sup>2</sup>For two or more fixtures, allow 1 3/8" between fixtures or 3/4", minimum, between cutouts.

2. Assemble yokes and side rails.
3. Place yoke and side rail assembly above ceiling, through aperture.
4. Attach flange to fixture.
5. Connect power feed to fixture.
6. Attach fixture and flange assembly to yoke and side rail assembly.

For complete instruction details, refer to instruction sheet PIN001200.

