

Lightline® Direct Softshine™ Suspended Installation Planning Guide

Type:


Project:

Rectangular 3 5/8" x 4 1/16"

LLML


UNIVERSAL MOUNTING BRACKET (F1)

Standard mounting for T-bar (grid) ceilings



HORIZONTAL J BOX MOUNT (F2)


Optional mounting for hard ceilings




Caution:

- Ceiling must be adequately reinforced at support locations — by others.
- Junction box may be subject to additional loads during installation and relamping.

JOINING DIAGRAM



WEIGHT AND SUPPORT SPACING FOR SOFTSHINE INDIVIDUAL SECTIONS



PLAN VIEW

Lightline® Direct Softshine™ Suspended Installation Planning Guide

Type:

Project:




Rectangular 3 5/8" x 4 1/16"

LLML


WEIGHT AND SUPPORT SPACING FOR SOFTSHINE ROWS

A row will consist of a starter, joiner(s) if the row is long enough, and an ender section. Support locations for each section type are shown below.


STARTERS



JOINERS



ENDERS



PLAN VIEW

Key:
● Support location

Lightline® Direct Softshine™ Suspended Installation Planning Guide

Type:

Project:

Rectangular 3 5/8" x 4 1/16"

LLML

WEIGHT AND SUPPORT SPACING FOR SOFTSHINE ROWS CONT.

To determine suspension spacing:

1. Check catalogue number for **row length** and **max section type**

Example: LLML 1 28T5 SSH **24FT4IN R12** 277 GEB10 SCT LP835 F1/18 C100

row length **max section type**

2. Check chart below to determine the type, quantity and length of sections per specified **row length** and **max section type**.

Max Section Type R12					
Section Type	Starters		Enders		
	No. S12	No. J12	No. E12	No. E8	No. E4
Section Length	10'-5 1/2"	10'-3"	10'-5 1/2"	7'-0 1/2"	3'-7 1/2"
17FT6IN	1			1	
20FT11IN	1		1		
24FT4IN	1	1			1
27FT9IN	1	1		1	
31FT2IN	1	1	1		
34FT7IN	1	2			1
38FT0IN	1	2		1	
41FT5IN	1	2	1		
44FT10IN	1	3			1
48FT3IN	1	3		1	
51FT8IN	1	3	1		
55FT1IN	1	4			1
58FT6IN	1	4		1	
61FT11IN	1	4	1		
65FT4IN	1	5			1
68FT9IN	1	5		1	
72FT2IN	1	5	1		
75FT7IN	1	6			1
79FT0IN	1	6		1	
82FT5IN	1	6	1		
85FT10IN	1	7			1
89FT3IN	1	7		1	
92FT8IN	1	7	1		
96FT1IN	1	8			1
99FT6IN	1	8		1	

Max Section Type R8				
Section Type	Starters		Enders	
	No. S8	No. J8	No. E8	No. E4
Section Length	7'-0 1/2"	6'-10"	7'-0 1/2"	3'-7 1/2"
10FT8IN	1			1
14FT11IN	1		1	
17FT6IN	1	1		1
20FT11IN	1	1	1	
24FT4IN	1	2		1
27FT9IN	1	2	1	
31FT2IN	1	3		1
34FT7IN	1	3	1	
38FT0IN	1	4		1
41FT5IN	1	4	1	
44FT10IN	1	5		1
48FT3IN	1	5	1	
51FT8IN	1	6		1
55FT1IN	1	6	1	
58FT6IN	1	7		1
61FT11IN	1	7	1	
65FT4IN	1	8		1
68FT9IN	1	8	1	
72FT2IN	1	9		1
75FT7IN	1	9	1	
79FT0IN	1	10		1
82FT5IN	1	10	1	
85FT10IN	1	11		1
89FT3IN	1	11	1	
92FT8IN	1	12		1
96FT1IN	1	12	1	
99FT6IN	1	13		1

3. To determine the support locations, layout the row based on the required section types and lengths for the row length. Note that starter and ender section lengths differ from joiner lengths. A row will always end with the smallest section type (E4<E8<E12).

Note:

If a suspension point falls on the ceiling grid, adjust the provided fixture joining hardware to move the suspension point.


EXAMPLES

Catalogue Number: LLML 1 28T5 SSH **14FT11IN R8** 120 GEB10 SCT LP835 F1/18 C100

Max Section Type R8				
Section Type	Starters		Enders	
	No. S8	No. J8	No. E8	No. E4
Section Length	7'-0 1/2"	6'-10"	7'-0 1/2"	3'-7 1/2"
Row Length	14FT11IN	1		1

Key:

● Support location



Lightline® Direct Softshine™ Suspended Installation Planning Guide

Type:

Project:


Rectangular 3 5/8" x 4 1/16"
LLML

EXAMPLES CONT.

Catalogue Number: LLML 1 28T5 SSH 17FT6IN R8 277 GEB10 SCT LP830 F1/24 C100

Max Section Type R8				
	Starters	Joiners	Enders	
Section Type	No. S8	No. J8	No. E8	No. E4
Section Length	7'-0 1/2"	6'-10"	7'-0 1/2"	3'-7 1/2"
Row Length	17FT6IN	1	1	1

Key:
● Support location



Catalogue Number: LLML 1 54T5HO SSH 27FT9IN R12 277 GEB10 SCT LP835 F1/18 C100

Max Section Type R12					
	Starters	Joiners	Enders		
Section Type	No. S12	No. J12	No. E12	No. E8	No. E4
Section Length	10'-5 1/2"	10'-3"	10'-5 1/2"	7'-0 1/2"	3'-7 1/2"
Row Length	27FT9IN	1	1	1	

