



CAUTION:
UNLOAD SPHERE ONTO A PROTECTED
SURFACE, FOAM, MAT OR ANY SOFT SURFACE
TO KEEP DESIGN FROM DAMAGE.

INSTALLATION OF SPHERE:
PLACE FOUR LOOP SLINGS UNDER SPHERE AND PICK UP ON ALL
FOUR LOOPS. PLACE IN PREPARED HOLE (SEE SPEC. FOR SIZE OF
HOLES) FILLED WITH CEMENT, REMOVE LOOPS, LET CURE FOR
THREE DAYS.

