

Mar-Flex 5000 Horizontal Installation Instructions

- 1) Horizontal surface should be dry and swept free of any loose debris and/or dust.
- 2) Apply Mar-Flex 5000 by spraying, brushing or rolling to the surface at a minimum of 100 mil dry thickness.
- 3) Allow the Mar-Flex Pro to cure out approximately 3-4 hours. The product will not totally be set up, but will allow for adherence of the Drainage Board Type III™.
- 4) After 3 – 4 hours, unroll the Drainage Board Type III. Place gray side down over membrane. Note: The Drainage Board Type III is a multi-directional board.
- 5) Place the next roll directly up against the end of the preceding roll.
Note: It is important to make sure that there is no more than a 1/4" gap. This prevents concrete or any debris from entering water flow channels.
- 6) Use any industrial adhesive to secure overlapping fabric into place.
- 7) After completing installation, allow a minimum of 24 hours set time.
- 8) After 24 hours, pour desired thickness of concrete over Type III.
- 9) It is then recommended to use the Mar-Flex Drain-A-Way Type 12" to remove the water that is drained through the Type III.

Note: All core joints must be covered by fabric overlay.