

# DriftClip® DSLB Installation Instructions

## Vertical Deflection & Drift @ Deck Edge



Large Step Bushing  
(Engineered for PAF  
or 1/4"-20 Screw  
to structure)

Standard Step Bushing  
(Engineered for #12  
screw to stud)

**DriftClip® DSLB**

Step Bushings are pre-installed. Do not remove unless otherwise indicated.

Structure

Attachment to Structure per Design Specifications

Fasteners should be installed through each step bushing.

Stud

#12 Screw

Fasteners should be installed through each step bushing.

For Installation, Technical, or Submittal questions, contact TSN at (888) 474-4876.

Email us at [tsn@steelnetwork.com](mailto:tsn@steelnetwork.com).

Visit [www.steelnetwork.com](http://www.steelnetwork.com) and discover the value of each TSN Solution.