


Installation Instructions

1800i Wall Guard


Please read all instructions before installing the wall guard.

FIG. 1



1. Determine height of wall guard on wall. Measure down $2\frac{15}{16}$ " and $6\frac{5}{8}$ " and snap a level chalk line at each mark. Mark mounting holes leaving allowance for end caps, outside corners and inside corners. See figure 1.


FIG. 2



2. Drill marked holes on wall using a $\frac{1}{4}$ " drill bit and position Alligator anchors into holes. Mount retainer supports on wall and tighten screws to secure. See figure 2. With lengths over 12', a splice is recommended between vinyl butt joints for added support. See figure 2a.

NOTE: For concrete or brick wall installation, drill $\frac{1}{4}$ " holes, $\frac{3}{8}$ " from end of retainer for end caps/corners.

FIG. 2A




Installation Instructions

1800i Wall Guard

- Slide end caps and corners onto the retainer support and secure, leaving a $\frac{1}{16}$ " gap between returns/corners and retainer to allow for adjustment. See Figure 3.

FIG. 3



NOTE: For concrete or brick wall installation, use #10 x 1 $\frac{3}{4}$ " Phillips pan head screws to secure end caps and corners.

- Cut the impact bumper to the length between the inside edge of the end caps/corners. Position and snap bumper in place. Cut the vinyl cover to length between end caps and/or corners. (Note: Trim factory edges square before installation). Position the cover on retainer and adjust returns and/or corners for a tight fit. Starting at one end of retainer supports, push cover over the retainer supports until it snaps into place. See Figure 4.

FIG. 4

