



Simple Sewing Instructions

- 1) Turn top $\frac{3}{8}$ " of cubicle fabric
- 2) Lay narrow selvedge of EZE-Mesh over the raw edge and sew with $\frac{1}{4}$ " gauge double-needle machine for a neat, smooth finish without puckering

NOTE: Please examine EZE-Mesh carefully before cutting. EZE-Mesh flaw factor is 6%. Flaws include, but are not limited to, tears, splits and/or waves. Height sizes can vary $+1\frac{1}{2}$ " -1 ".

*Exclusive
Labor Saving
Features*

Please view the informative video on ezemesh.com that depicts additional sewing instructions

IPC.536/REV.1