

Installation Instructions

Overhead Signage

FIG. 1




FIG. 2







FIG. 3



Tegular Gridclip



Flush Gridclip

FIG. 4




FIG. 5





FIG. 6



1. Sign Location

- The ADA (Americans with Disabilities Act) and Building Codes regulate the placement of signage in buildings. Follow building codes when installing overhead signage. ADA recommendation: 4.4.2 Head Room. Walks, halls, corridors, passageways, aisles or other circulation spaces shall have 80 inches (2.03m) minimum clear head room. (See Figure 1)


2. Gridclip Installation

1. Attach Gridclips to the ceiling grid. Use flush gridclips for flush ceiling tiles and tegular gridclips for tegular edge ceiling tiles. Attach track to the Gridclips by snapping track into each gridclip. (See Figure 2)
2. If ceiling grid is located so Gridclips cannot be attached 2" from each end use a combination of toggle bolts and gridclips. Drill 1/4" holes in track. Mark and drill 3/4" holes in ceiling. Attach gridclips to the ceiling grid. Assemble toggle bolt assembly on track. Attach track to the Gridclips by snapping track into each gridclip. Push bolt assembly into ceiling holes and tighten until track is secure. (See Figure 3)
- b. Slide "T" aluminum mounting channel on top of sign into track. Slide end caps on each end of track. Drill 3/32" hole through side of end cap and track. Secure end cap to track with screw. (See Figure 4)
Note: For narrow corridor conditions, slide left "T" mounting channel into left end of track (See Figure 5). Continue to slide in the left "T" mounting channel until the right "T" mounting channel can be inserted into the right end of the track (See Figure 6). Complete installation detailed in step 2b.

Installation Instructions

Overhead Signage

FIG. 1



3. Drywall or Concrete Ceiling Installation

- Drill 1/4" hole in aluminum track. Mark and drill 3/4" (drywall ceiling) or 1/4" (concrete ceiling) holes in ceiling. (See Figure 1)

1. Drywall Ceiling - Assemble toggle bolt assembly on track. Push bolt assembly into ceiling holes and tighten until track is secure. (See Figure 2)
2. Concrete Ceiling - Push Alligator anchors into ceiling holes. Position track over anchors and secure with screws. (See Figure 3)

FIG. 2





FIG. 3



- Slide "T" aluminum mounting channel on top of sign into track. Slide end caps on ends of track. Drill 3/32" hole through side of end cap and track. Secure end cap to track with screw. (See Figure 4)

Note: For narrow corridor conditions, slide left "T" mounting channel into left end of track (See Figure 5). Continue to slide in the left "T" mounting channel until the right "T" mounting channel can be inserted into the right end of the track (See Figure 6). Complete installation detailed in step 3c.

FIG. 4




FIG. 5




FIG. 6

