

Clean-up and Maintenance

Cubicle Tracks

Cubicle tracks require very little maintenance. If carriers do not move smoothly, check the track for binding. If the track is clear of debris, spray the inside of the track with a light coating of silicone spray. Be careful not to spray the curtains and wipe any excess spray from the track.

Standard Cubicle Curtains

1. Wash Cycle: Wash as any standard colored fabric, with water temperature not to exceed 160°F. Detergents: Use a synthetic detergent. DO NOT use a caustic soap or bleach.
2. Extraction Cycle: Extraction depends on the size of the load and equipment used. Fabric requires 2-4 minutes of extraction.
3. Drying Cycle: Tumble dry for 3-5 minutes on the synthetic cycle. DO NOT overload the dryer. Excessive heat will decrease the permanent press feature of this fabric. Remove curtains immediately from the dryer after the cycle is complete.
4. DO NOT put curtains through a mangle.

Shield Cubicle Curtains

1. Wash Cycle: Remove stains with a damp cloth/sponge with detergent. Fabric also may be laundered by steam cleaning or commercial washing, with water temperature not to exceed 160° F. Do not add softener. Repeated washing does not destroy inherent properties of the Shield fabric.
2. Extraction Cycle: Extraction depends on the size of the load and equipment used. Fabric requires 2-4 minutes of extraction.
3. Drying Cycle: Tumble dry for 3-5 minutes on the synthetic cycle. DO NOT overload the dryer.
4. Finishing: If fabric is folded when drying cycle is completed, no ironing is required. Occasionally light touch-up with hand iron (275°), if desired.

Bedspreads

1. Wash separately (do not combine with other products)
2. Wash darks separately
3. Machine wash (120° F - 160° F)
4. Tumble dry – medium – remove promptly
5. Use steam iron – low setting
6. DO NOT DRY CLEAN
2-3% shrinkage anticipated in washing cycle

Draperies

Draperies should be cleaned as seldom as possible with dusting or vacuuming done on an "as needed" basis. Frequent or repeated cleanings may remove some of the "life" from a drape eventually yielding limpness to the material. Dry cleaning is the preferred method for cleaning.

IPC.532/REV.8



P.O. Box 406 · Muskego, Wisconsin 53150 USA
inprocorp.com
Nationwide 800.222.5556/Fax 888.715.8407
International Sales 262.679.5521/Fax 262.679.5524

INPRO CORPORATION
Interior and Exterior Architectural Products

Clean-up and Maintenance

Vinyl Shower Curtain Washing Instructions

RECOMMENDED

1. Sponge with warm mild soap & rinse with clear water.

MACHINE WASHING

1. Relatively cool water temperature not to exceed 120°F.
2. Use mild soap solution, do not use commercial detergent / chlorine bleach.
3. Air dry at low temperature.

Single Side Prints Washing Recommendations

1. No fabric softener or bleach is used.
2. Machine wash or tumble dry low not to exceed 120°.
3. Do not wash polyester bedspreads with any cotton items or in a machine which has cotton lint residue from previous washings.
4. Wash with a mild detergent promptly after spotting so stains will release properly.

IPC.532/REV.8



P.O. Box 406 · Muskego, Wisconsin 53150 USA
inprocorp.com
Nationwide 800.222.5556/Fax 888.715.8407
International Sales 262.679.5521/Fax 262.679.5524

INPRO CORPORATION
Interior and Exterior Architectural Products