

STOP!

**Do not install until you have read these instructions
Call 800.465.6909 with any questions**

HANDLING AND INSTALLATION INSTRUCTIONS

**David Rockwell for Maya Romanoff Blanket™ Wallcoverings
(MR-BK series)**

QUICK FACTS

- Paste: Maya Romanoff's MR-RA-888-1 or MR-RA-888-5 or a good quality clear, strippable, pre-mixed, vinyl, adhesive.
- Table-trim.
- Prepaste the wall only—do not paste product.
- Please read the following installation instructions before proceeding.
- **IF YOU DO NOT FOLLOW OUR INSTALLATION INSTRUCTIONS, MAYA ROMANOFF WILL NOT ACCEPT RESPONSIBILITY FOR THE INSTALLATION—YOU WILL BE INSTALLING AT YOUR OWN RISK.**

GENERAL GUIDELINES

- BK-01 and BK-03: 7" HORIZONTAL REPEAT
- Inspect goods carefully. No returns on cut goods. Grade carefully for color flow.
- Confirm that you have the correct color and product before installing. Additional yardage from this dye lot may not be available.
- **No allowances will be made after THREE (3) drops—Call 800.465.6909 immediately if you encounter any difficulties.**
- No claims allowed for labor charges or consequential damages under any conditions.
- Wallcoverings can display certain irregularities that are inherent to the manufacturing process.

ACTIONS TO AVOID

- **Paste wall directly—DO NOT PASTE WALLCOVERING.**
- Do not double-cut on the wall.
- Do not trim from the front or get paste on the front.
- Do not rub face of product with a stiff brush.
- Do not pull panels once they have been placed on the wall: this will cause the seams to open after the product dries
- Avoid direct or bright sunlight. Not guaranteed against fading or color change.

05/01/11

CONTINUED 



MAYA ROMANOFF

Chicago Headquarters: 3435 Madison, Skokie, IL 60076 † 1.773.465.6909 † 1.773.465.7089 www.mayaromanoff.com

1

STOP!

**Do not install until you have read these instructions
Call 800.465.6909 with any questions**

HANDLING AND INSTALLATION INSTRUCTIONS

**David Rockwell for Maya Romanoff Blanket™ Wallcoverings
(MR-BK series)**

PRIMER

- Paint the wall the color of the product with a good quality, non-sealing flat latex wallpaint. Avoid super sealing wall prep products. They can cause product to bubble.
- Do not install on sealed walls without hanging lining paper.
- Walls must be completely dry before installation can begin.
- Apply a coat of Maya Romanoff's MR-RA-838-1 or MR-RA-838-5 or a good quality HEAVY DUTY, CLEAR PRE-MIXED, VINYL, LOW WATER CONTENT adhesive* to the wall.

ADHESIVE

- Use Maya Romanoff's MR-RA-888-1 or MR-RA-888-5 or a good quality CLEAR, STRIPPABLE, PRE-MIXED, VINYL adhesive*. Apply evenly and adequately. Apply paste thicker where seams will fail.
- **Paste wall directly—DO NOT PASTE WALLCOVERING.**
- Avoid getting paste on face of product.

TRIMMING

- Trim with a very sharp, single edge razor blade. USE A NEW BLADE FOR EACH CUT.
- This product cannot be double-cut on the wall; trim the material on a table.

HANGING

- DO NOT smooth face of product with a bristled brush or any other textured smoothing implement.
- Gently smooth product to the wall using a plastic smoother. Smooth continuously to remove any bubbles.

*For more information on Maya Romanoff's MR-RA-888-1 or MR-RA-888-5, check out www.mayaromanoff.com.

05/01/11



MAYA ROMANOFF®

Chicago Headquarters: 3435 Madison, Skokie, IL 60076 t 1.773.465.6909 f 1.773.465.7089 www.mayaromanoff.com