# STOP!

# Do not install until you have read these instructions Call 800.465.6909 with any questions

# **HANDLING AND INSTALLATION INSTRUCTIONS**

Sheer Hemp™ Wallcovering (MR-HP-1 series)

Product woven with natural fibers. Slubs/other irregularities will appear from time to time within some rolls.

# **QUICK FACTS**

- Paste: Maya Romanoff's MR-RA-888-1 or MR-RA-888-5 or a good quality clear, strippable, pre-mixed, vinyl adhesive.
- Walls should be mirror smooth.
- Table-trim from the back.
- Prepaste the wall.
- Relax 8-10 minutes.
- Please read the following installation instructions before proceeding.
- IF YOU DO NOT FOLLOW OUR INSTALLATION INSTRUCTIONS, MAYA ROMANOFF WILL NOT ACCEPT RESPONSIBILITY FOR THE INSTALLATION—YOU WILL BE INSTALLING AT YOUR OWN RISK.

## **GENERAL GUIDELINES**

- Inspect goods carefully. No returns on cut goods. Grade carefully for color flow.
- Confirm that you have the correct color and product before installing. Additional yardage from this dye lot may not be available.
- No allowances will be made after THREE (3) drops—Call 800.465.6909 immediately if you encounter
  any difficulties.
- · No claims allowed for labor charges or consequential damages under any conditions.
- Wallcoverings can display certain irregularities that are inherent to the manufacturing process.
- Walls should be MIRROR-SMOOTH. Lining paper should be used if walls have imperfections.
- NO SIDE MATCH.

# **ACTIONS TO AVOID**

- Do not reverse roll product or reverse hang.
- Do not seal your walls.
- Do not trim from the front or get paste on the front.
- Do not crease wallcovering.
- Do not rub face of product with a stiff brush.
- Do not use a seam roller to set the seams—instead use a soft bristled nylon brush.
- Avoid soaking the paper in water or getting the wallcovering excessively wet. This can cause shrinkage and opening of seams as the wallcovering dries.
- · Do not pull panels once they have been placed on the wall: this will cause the seams to open after the product dries.
- Avoid direct or bright sunlight. Not guaranteed against fading or color change.

05/01/11 CONTINUED







# Do not install until you have read these instructions Call 800.465.6909 with any questions

# **HANDLING AND INSTALLATION INSTRUCTIONS**

Sheer Hemp™ Wallcovering (MR-HP-1 series)

Product woven with natural fibers. Slubs/other irregularities will appear from time to time within some rolls.

### WALL PREPARATION

- Paint the wall the color of the product with a good quality, non-sealing flat latex wallpaint.
- Do not install on sealed walls without hanging lining paper.
- Walls must be completely dry before installation can begin.
- Apply a coat of Maya Romanoff's MR-RA-888-1 or MR-RA-888-5 or a good quality CLEAR, STRIPPABLE, PRE-MIXED, VINYL adhesive\* to the wall.

#### TRIMMING

- Trim with a very sharp, single edge razor blade. USE A NEW BLADE FOR EACH CUT.
- Pre-trim on a table from the back side.

## **ADHESIVE**

- Use Maya Romanoff's MR-RA-888-1 or MR-RA-888-5 or a good quality CLEAR, STRIPPABLE, PRE-MIXED, VINYL adhesive.\*
- PRE-PASTE THE WALL with adhesive before hanging.
- Apply evenly and adequately to back of product. Along the edges, paste thicker to avoid seams opening.
- DO NOT fold after pasting, creases may be difficult to smooth out.

### **RELAXING TIME**

- It is essential to allow wallcoverings sufficient relaxing time to avoid bubbling, shrinking and seam opening. Allow the paste enough time to soak into a sheet before hanging.
- Usual Relaxing Time: 8-10 minutes
- Do a small test strip to determine the proper relaxing time.
- WIPE OFF EXCESS PASTE IMMEDIATELY WITH A SOFT DAMP CLOTH. DO NOT SCRUB. DO NOT RUB.

#### HANGING

- Adhere product to the wall using a soft bristled nylon brush.
- Gently smooth product to the wall using a soft bristled nylon brush. Smooth continuously to remove any bubbles.
- \*For more information on Maya Romanoff's MR-RA-888-1 or MR-RA-888-5, check out www.mayaromanoff.com.

05/01/11

