



--INSTRUCTIONS:

1. Remove drawer from media connector table (Figure 1).
2. Using eight (8) 8 x 3/4" screws, attach two (2) flat plates so they extend out halfway from the underside of the Media Console (Detail A).
3. Position right media connector table over protruding flat plates.
4. Align fronts of cabinets and clamp together.
5. Secure right media connector table to flat plates with eight (8) 8 x 3/4" screws.
6. Using six (6) 8 x 1-1/2" Phillip Flat Head Screws, secure both units together thru prebored holes inside cabinet (Detail A).
7. Re-install drawer media connector table to complete.