

INSTALLATION HANG-STRAIGHT STEM SPECTRUM LIGHTING FIXTURES

WARNING:

BE CERTAIN ALL POWER IS OFF. WIRE ACCORDING TO LOCAL AND NATIONAL CODES. THIS PRODUCT SHOULD BE INSTALLED BY A QUALIFIED ELECTRICIAN

**NOTE: CANOPY RECOMMENDED FOR 50 LB
MAX STATIC LOAD**

1. ATTACH HANG STRAIGHT "DROP" STRAP TO JUNCTION BOX. (BE CERTAIN BOX IS SUPPORTED BY STRUCTURAL CEILING)
2. THREAD LEADS THROUGH STEM, THREAD STEM ONTO HEX FITTING AT TOP OF FIXTURE. BE CERTAIN CONNECTION IS SECURE (USE LOCTITE IF NECESSARY)
3. **SLIP CANOPY ONTO STEM.**
4. LOOSELY THREAD HANG-STRAIGHT BALL ONTO TOP OF STEM. PASS ALL LEADS THROUGH STRAP AND INTO JUNCTION BOX.
5. MAKE ELECTRICAL CONNECTIONS ACCORDING TO CODE.
6. SLIDE HANG STRAIGHT BALL/STEM ASSEMBLY THROUGH OPENING AT SIDE OF STRAP.
BE CERTAIN TAB ALIGNS WITH GROOVE IN "BALL"
(DRAWING AT RIGHT)
7. MAKE ELECTRICAL CONNECTIONS ACCORDING TO CODE. **TIGHTEN BALL ON STEM**
8. BRING CANOPY UP TO CEILING LEVEL, **(FLEX ON SIDES OPPOSITE SLOTS)**
CAPTURE TABS ON CEILING STRAP WITH SLOTS IN CANOPY

