


Monaco, Capri & Como: Installation

Recommended installation using Standard Drain: VA code STD-UNI-PC, BN, PN, PB, ORB

The fitting of the base and installation of the tub will be seen as acceptance of quality.

We strongly recommend that you use a suitably qualified installer. Instructions must be adhered to. We cannot accept responsibility of incorrect installation. Victoria & Albert customer service representatives are not qualified to give advice on DIY installations.

Note We recommend the plastic and foam packaging remains on the tub until all the construction and decoration is completed.
ABS pipe should always be used below floor level.

- a. Position tub and mark the center of the drain outlet and trace the inside edge of the tub onto the floor.
 - b. Assemble tub drain and mark location of drain hole through floor.
- 
- c. Remove tub and rough in drain lines, ensuring plastic drain connector is no more than 1/4 inch above the finished floor level.
 - d. Secure the four wooden blocks supplied (90 degree edges facing outwards) to the floor along the inside edge of the tracing - two to both the front and rear straight edges.
 - e. Reposition tub over wooden blocks to check alignment and contact with tub.
 - f. Fit tub drain and check for leaks or alternatively assemble tub drain and connect to rough in.
 - g. Generously apply 100% clear silicone supplied to the outside vertical faces of the wooden blocks and lower the tub into position.



- h. Connect tub drain and tighten.
- i. For the ultimate finish, we recommend applying a white silicone bead around the base of the tub.
- j. Allow 12 hours before moving tub for the first time.

Questions?

1.800.421.7189