California Accent Lighting

Installation Instructions

To: Installers – This Product Must be Installed by a Qualified Electrician

Re: AlumLite Series – Line Voltage

Step 1 - Remove Cap Using a Flat Screwdriver to Pry Open

Step 2 - Mount Bottom Piece to a Secure Surface using Fasteners Appropriate to Site conditions.

Step 3 – Knock Out Appropriate Knock Outs' from End Caps.

Step 4 – Mount End Caps at the Beginning and End of Run by Sliding Base Plate into Bottom Piece and Securing with a Screw Provided.

Step 5 – Wire Per N.E.C. and Any Applicable Local Codes.

Step 7 – Snap Cover into Bottom Piece

Step 8 - Install Lamps

- AlumLite Series must be installed in accordance with the NEC or CEC as applicable.
- Mounting means (Screw) shall be provided at intervals of 4'.