



Instructions:

1. Install one electrical box wired for fixture power and one electrical box (or structural blocking capable of supporting 50 pounds) at 48-1/8" apart center to center. If structural blocking is used instead of an electrical box, 1-1/4" diameter X 1/4" deep clearance is required for the Aircraft cable clip.
2. Attach Mounting brackets to junction boxes or structural blocking (by others).
3. Thread cable through Mounting bracket and under Aircraft cable clip.
4. Make sure cables are even and tighten Aircraft cable clip screws.
5. Slide canopy onto cable and tighten set screws to mounting bracket.
6. Install cables into Griplocks in fixture. (See Griplock detail above)
7. Loosen powered electrical box canopy.
8. Feed power cord through canopy and securely attach a wire tie to cord on electrical box side for strain relief.
9. Make all necessary wire connections per code.
10. Reattach canopy.

When using electrical equipment, basic safety precautions should always be followed, including the following:
 1) Read all instructions carefully before installing and save for future use. Make sure all connections are in accordance with the National Electrical Code and local regulations.
 2) To avoid possible electric shock, be sure the power supply is turned off before servicing or installing the fixture. Service should be performed by qualified personnel.
 3) These instructions may not cover all details or variations. If additional information is needed, please contact Visa Lighting.

Drawing : 760519XX
Rev : A **Sheet 1 of 1**


VISA LIGHTING
 An Oldenburg Group Company
 1717 West Civic Drive Milwaukee, WI 53209
 414-354-6600
 Design Modification Rights Reserved
 © Visa Lighting 2004

INSTALLATION INSTRUCTIONS: CP3750
Fixture family name: Ascent

Description: INST SHEET CABLE MOUNTING

Drawing : 760519XX
 Rev: A

Sheet 1 of 1
 Eng: GJW

Date drawn: 8/18/2004