

1. Hook brackets to panel top slotted rail. Lightly hammer into place to tighten.

2. Position across from each other approximately 4" to 12" from the end of the panel. 4" for a 24" long screen and 12" for a 60" long screen.

3. Slide visual privacy screen down into brackets and brackets may have to be pushed apart for screen to fit between.

4. Screen sits on top of the panel top trim.

