

## Decorative Top

### Tools Required

- Drill
- Tape Measure
- #2 Phillips Head Bit
- Screw Gun
- $\frac{3}{16}$ " Drill Bit

### Hardware Required

- #8 x  $1\frac{1}{2}$ " Panhead

### Installation

1. Decorative tops can be added to the top of a storage unit. Longer tops can be used to span multiple storage units. All decorative tops are equipped with spacer rails and foam tape to create a  $\frac{1}{8}$ " reveal line between the storage unit and top. (Figure A).
2. Tops (18" to 72" wide) are shipped with two loose spacers. Longer tops (78" to 108" wide) are shipped with four loose spacers. These spacers can be positioned underneath the top to help support the weight of the top. Peel off the double stick tape and position as needed.  
**Note:** *Spacer needs to be attached to top panel, not end panels. (Figure A).*
3. To attach top to cabinets, measure inside of the cabinet 3" from sides. Bore thru the inside of top panel using  $\frac{3}{16}$ " drill bit. Attach top using  $1\frac{1}{2}$ " panhead screws. (Figure A).

Figure A

