

High Low End Trim

Figure A

Tools Required

- Cordless driver with magnetic post and following tips
 - M5 Hex Drive

Hardware Required (Included)

- 2 1/4"-20 X 60mm (2 3/8") Connector Bolt
- 1 1/4"-20 X 12mm (1/2") Connector Nut

Installation

1. Unpack End Trim and all hardware.
2. Align End Trim with mounting holes as shown in Figure A.
3. Connect End Trim with a Connector Bolt on the top and a Connector Bolt/Connector Nut combination on the bottom as shown in Figure A.

