

Component Pedestal

Tools Required

- Cordless Drill
- #2 Phillips head bit

Hardware Included

- #8 x 3/4" panhead screws

Installation

1. Place worksurface face down on clean flat surface.
2. Position pedestal upside-down on underside of worksurface. The pedestal should be positioned so the sides are 1/16" from edge of worksurface and 1/16" from the back edge, (Figure A)
3. Attach pedestals metal rails to worksurface using #8 x 3/4" panhead screws.

Note: Make sure drawers are returned to their original location.

Figure A

