

Upmount Overhead Shelves and Cabinets

Tools Required

- Cordless Drill
- #2 Philips Head Bit
- Tape Measure

Hardware Required

- #8 x 3/4" Phillips Flathead Screw
- Ganging Bolts

Installation

Important:

- 2 people required for proper installation.
- Multiple Cabinets must be ganged together **prior** to installation. See Priority Highback Assembly Instructions 2008506.
- Cabinets and Overheads **not** to be used in conjunction with Top Caps.

1. When U-Leg Frame and Tiles have been fully assembled, and **prior** to installing Worksurfaces, Shelf or Cabinet should be carefully lifted over U-Leg Frame and placed evenly on Overhead Stanchion Brackets. (Figure A)
2. End of Shelf or Cabinet should be brought flush with outside edge Overhead Stanchion Bracket, then centered from front to back.
3. Secure Shelf or Cabinet to Overhead Stanchion Brackets using #8 x 3/4" Phillips Flathead Screws (4 per Overhead Stanchion Bracket). (Figure A)

Tips

1. Cabinets can be installed facing opposite directions if desired, as shown in Figure A. Faces of back panel and door to be flush when ganged together for proper alignment.

Figure A

