

Ordering Information

Applicable product:	
Alterna™ handles	K-6504-2

Installation Notes

For installation on cast iron baths, collar should be installed with flange facing downward. Opening in cast iron must be 1-7/8" D. minimum.

