

### Product Information

Applicable valve:	Handles are ADA compliant. <b>ADA</b>	
Shower only trim*, sculpted lever handle, showerhead	K-T10276-4	shown
Shower only trim*, traditional lever handle, showerhead	K-T10276-4A	shown
Valve only trim*, sculpted lever handle	K-T10277-4	shown
Valve only trim*, traditional lever handle	K-T10277-4A	shown
Sculpted NPT diverter bath spout	K-10280-4	not shown
Traditional NPT diverter bath spout	K-10280-4A	not shown
Sculpted slip-fit diverter bath spout	K-10281-4	shown
Traditional slip-fit diverter bath spout	K-10281-4A	not shown

\*Rite-Temp valve must be ordered to complete faucet.

Recommended Accessories	
HiFlow Rite-Temp thin wall installation kit*	88526
* For K-306-KS valve in a fiberglass or acrylic installation.	

Required Accessories	
Rite-Temp valve without stops <b>OR</b>	K-304-K
Rite-Temp valve with stops <b>OR</b>	K-304-KS
HiFlow Rite-Temp valve with stops <b>OR</b>	K-306-KS
Rite-Temp valve with PVC connections <b>OR</b>	K-304-KP
Optional Accessories	
Forté deep roughing-in kit for Rite-Temp valve	1025388

### Installation Notes



**WARNING: Risk of damage to the K-306-KS valve assembly.** When using the K-306-KS valve in a fiberglass or acrylic installation, use the thin wall installation kit (88526).

Install this product according to the installation guide.

Install Rite-Temp valve according to valve installation guide.

Avoid cross-flow conditions. Do not install shut-off device on either valve outlet.

Cap shower outlet if deck-mounted spout, diverter, or handshower is connected to the spout outlet.

Install straight pipe or tube drop of 7" (17.8 cm) to 18" (45.7 cm) with single elbow between valve and wall-mount spout.

