

# m o o o i<sup>®</sup>



## Eurolantern suspended

The Eurolantern arrives as a cylinder of stretchable fabric which when pressed down unfolds into a beautiful Lantern

---

<b>Designer</b>	Moooi Works
<b>Year of design</b>	2008
<b>Material</b>	Stretched fabric over a metal and plastic foldable framework, chrome pendant
<b>Additional</b>	The Eurolantern has a clever folding mechanism, saving volume and enhancing product interaction

---



---

## Detailing



The Euro Lantern construction is finished with a decoratively patterned ring.

Please refer to the manual for more information on unfolding and installation

---

## Colour




White & White



Black & White



Red & White



Pattern & White

The colour choice is applied to the top half, the bottom half is always white

---

## Technical



E27 x I

15 W MAX type A

Cable length 4M (transparent)

Cable length 10M on request

Plastic white canopy



E26 x I

25 W MAX type A

Cable length 4M (black)

Cable length 10M on request

Chrome Canopy

---

## Packaging

### Euro Lantern suspended Small

H 20cm | 7.9"  
W 23cm | 9.1"  
L 73cm | 28.7"

Weight including packaging:

3KG | 6,6 lb

Net product weight:

2KG | 4,4 lb

### Euro Lantern suspended Medium

H 20cm | 7.9"  
W 23cm | 9.1"  
L 113cm | 44.5"

Weight including packaging:

4,5KG | 9,9 lb

Net product weight:

3KG | 6,6 lb

---



## Cleaning Instructions

To clean the Euro Lantern, Moooi recommends using a sticky lint remover available from most good retail outlets. Gently roll the lint remover over the whole shade until all dust particles are gone. For tough stains Moooi recommends dab-cleaning any stained area with a little diluted detergent. Be careful not to rub the area as this can make the stain worse.

Always read the label of any cleaning product you wish to use.



## Main dimensions

52cm | 20.5"



35cm | 13.8"

82cm | 32.3"



55cm | 21.7"