

Care & Cleaning

Solid Surface Sinks

While Prism® sinks are extremely tough and durable. Like any fine material, it can be damaged if abused or mistreated. Review these care and cleaning instructions to assist you in understanding how easy it is to care for your Prism sink and how you can prevent more severe damage that may require professional repairs.

Normal Cleaning

Prism® sinks are non-porous so they can be easily wiped clean with a damp cloth or sponge and mild detergents or general-purpose cleaners. If you have a factory matte finish, abrasive cleaners may also be used. Periodically, it may also be helpful to go over the entire surface with an abrasive cleaner or a wet Scotch Brite®* pad to maintain a uniform appearance.

Spills and Stains

While most everyday spills can be removed with the cleaning techniques mentioned previously, some troublesome spills and stains such as food/hair dye, tea, and fruit drinks may require more aggressive cleaning. These items can be removed with a solution of 50/50 bleach and water allowed to sit for 15 minutes, drained and flushed with water. Follow with a general cleaner and flush with water. If you prefer, you may scrub with an abrasive cleaner on a factory matte finish.

Some Simple Precautions

DO NOT place hot pans directly from the burner or oven into the Prism® sink. Even though Prism sinks can withstand sustained temperatures up to 225°F, prolonged or extreme heat could cause yellowing and/or cracking.

DO NOT pour boiling water directly into your Prism® sink. Always run cool water at the same time. Allow hot grease to cool before pouring into disposal or sink.

Strong acids such as those found in drain cleaners, toilet bowls and oven cleaners should be used cautiously around Prism® sinks. If these items are accidentally spilled, wipe them up at once, flush with clear lukewarm water, and wipe with a clean sponge.

Repairing Scratches

Prism® sinks are usually supplied with a matte finish (unless specified otherwise) which is equivalent to wet sanding with 320-350 grit sandpaper or buffing with a Maroon Scotch Brite®* pad. For removing superficial scratches, use a wet Maroon Scotch Brite®* buffing pad until the scratches are removed. Clean thoroughly with soap and water and let dry. Note: deep scratches can be removed by first sanding lightly with 220-320 grit sandpaper. Then use a wet Maroon Scotch Brite®* pad to restore the finish (available from industrial supply houses or hardware stores).

For any damage; contact your fabricator/installer for repair.

***Registered trademark of 3M Corp.**

IPC.699/REV.1



Installation Questions?

Contact our Installation Hotline 866.EZINPRO
For Sales & Customer Service call 800.222.5556

INPRO CORPORATION®
Interior and Exterior Architectural Products