

General Installation Instructions

READ AND FOLLOW ALL SAFETY INSTRUCTIONS!
SAVE THESE INSTRUCTIONS AND DELIVER TO OWNER AFTER INSTALLATION

⚠ WARNING

To reduce the risk of death, injury or property damage from fire, electric shock, cuts, abrasions, falling parts, and other hazards:

- Service of the equipment must be performed by qualified service personnel.
- Installation and maintenance must be performed by a person familiar with the construction and operation of this product and any hazards involved. All applicable codes and ordinances must be followed.
- Read this document before installing, servicing, or maintaining this equipment or installing a lamp. These instructions do not cover all installation, service, and maintenance situations. If your situation is not covered, or if you do not understand these instructions or additional information is required, contact Peerless Lighting or your local Peerless Lighting Distributor.
- Read and follow all warnings and instructions provided by the lamp manufacturer.

⚠ WARNING

Before installing, servicing, or maintaining this equipment, follow these general precautions. To reduce the risk of electrocution:

- Make sure the equipment is properly grounded.
- Always de-energize the circuit and/or equipment before connecting to, disconnecting from, or servicing the equipment.

To prevent fixture row from over-current:

- By adding the input current of each fixture section marked on the fixture, the total current per power feed must not exceed the maximum line wire amperage marked on the fixture and the power feed cord/wire amperage rating whichever the least.

To reduce the risk of fire:

- Keep material away that can burn from hot lamp.
- Make sure lamps are correctly installed.
- Use supply conductors with a minimum installation temperature rating as specified on equipment.

To reduce the risk of personal injury from cuts, abrasions, or falling parts:

- Wear gloves to prevent cuts or abrasions from sharp edges when removing from carton, handling and maintaining this equipment.
- Do not use abrasive materials, glass cleaners or other solvents on reflector or lens. These substances may damage equipment and cause parts to eventually break and fall.
- Do not install a damaged fixture.

⚠ CAUTION

Observe lamp manufacturer's recommendations and restrictions on lamp operation, including but not limited to ballast type, burning position, replacement and cycling. Use only lamps that comply with applicable ANSI standards.

NOTICE: If lamp is marked (Hg) it contains mercury. Follow disposal laws. See www.lamprecycle.org

Peerless Lighting, a division of Acuity Brands Lighting, Inc., assumes no responsibility for claims arising out of improper or careless installation or handling of this product.

SAVE THESE INSTALLATION INSTRUCTIONS

Part Number: PIN004100 Revision: C Effective Date: 12/20/2010 ECO3618

These installation instructions are used for installing the following fixtures and kits:


Fixture			Endcap Kit
EGAM1	EGAM2		EGAMEP
EGCM1	EGCM2		EGCMEP
EGSAM1	EGSAM2	EGSAM4	EGSAMEP
EGSCM1	EGSCM2	EGSCM4	EGSCMEP

WARNING: Risk of fire and electrical shock. This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the production and the hazards involved

- A) Fixture Run Installation ----- page 1
B) Mounting Kit Accessory----- page 2


A) Fixture Run Installation

A.1 Hanging First Fixture




Adjustable Cable Option

1. Attach adjustable cable gripper (ACG) to fixture and tighten securely.



IMPORTANT




Do NOT insert cable into ACG prior to ACG being attached to fixture. Twisting the cable could cause gripper to become loose.

- 1) Peel adhesive protector off of gasket. Carefully position and adhere gasket to only the steel joiner bracket as shown. **DO NOT PLACE GASKET OVER HOUSING EXTRUSION.**
- 2) Connect male and female quick wire connectors.
- 3) Insert endcap with pins to the fixture feed end and secure by tightening the set screws.
- 4) Insert power feed cord through endcap cover center feed hole at the male quick connector end. Attach endcap cover to joiner with screws.
- 5) To hang the fixture, screw cable stud into joiner on each end of the first fixture. Raise fixture into position. Level the fixture by adjusting the cable studs.

LIGHTEGE™**MODULAR PENDANT FIXTURE
INSTALLATION INSTRUCTION**

Rev. D 2/07 ECO 3495

A.2 Joining Fixture Sections

- 1) Screw cable stud to the next fixture at the end with female quick wire connector.
- 2) Raise the fixture into position and connect quick wire connectors.
- 3) Bolt fixtures together. Be sure to align and level the fixtures for a smooth, straight row.
- 4) Loosen set screws on the pins. Slide pins to center of joint. Tighten set screws.
- 5) Repeat step 1 to 4 until last fixture in row is hung. Attach endcap and endcap cover to the last fixture.

B) Mounting Kit Accessories

Used On	Kit Name (Accessories)	
	Fixed Cable	Adjustable cable
Support location at normal power feed	EGAMFK, EGCMFK, EGSAMFK, EGSCMFK	ACGFKPLS
Support location at emergency power feed	EGAMEK, EGCMEK, EGSAMEK, EGSCMEK	ACGEKPLS
Support location without power feed	EGAMSK, EGCM SK, EGSAMSK, EGSCMSK	ACGSKPLS

P E E R L E S S ®

PEERLESS LIGHTING
P.O. BOX 2556
BERKELEY, CA 94702-0556
TEL: 510-845-2760
FAX: 510-845-2776