

Product Guide

User and Maintenance Information

Important Information:
Please save this product guide. Consider making a photocopy in order to keep one copy with the product and file the other for future reference.

Customer Centers:

United States

359 Gibson Hill Road
Chester, NY 10918

Office hours: 9-5 EST

Phone (800) 777-4244

Fax (800) 336-5948

(845) 572-3468

www.CommunityPlaythings.com

United Kingdom

Robertsbridge

E. Sussex TN32 5DR

Phone 0800 387 457

01580 883 301

Fax 0800 387 531

01580 883 331

www.CommunityPlaythings.co.uk



community playthings

F242 Locking Low Storage Shelves

Recommended Use

These low, open Shelves provide storage space without obstructing windows and walls. The unit can be rolled easily on the concealed 2" casters.

⚠ WARNING

- ▲ The Locking Storage Shelves should be opened, closed, and moved by a responsible adult. Keep children's fingers away when closing to avoid pinching.

⚠ CAUTION

- ▲ For indoor use only. This unit is not waterproof.

Assembly

The F242 comes in two cartons containing:

1. The F24R Right Shelving Unit
2. The F24L Left Shelving Unit

If your shipment is incomplete, please call your Customer Center.

To assemble the Storage Unit:

1. Remove the hinge pins from the F24R unit.
2. Slide both units together so that the hinges mesh.
3. Insert the hinge pins into the hinges from the top down.

Maintenance

Periodically inspect for cracks, breaks, and loose or missing parts. Remove the product from service when any condition develops that might make use unsafe.

Cleaning

Wipe the wooden parts with a damp cloth and mild detergent. Do not use excessive water.

Construction

The wooden components are manufactured from solid maple, finished with a durable clear finish. All edges and corners are rounded for safety and ease of cleaning. Backs are nylon loop fabric laminated to a durable plastic backing.

User Modifications

We cannot be responsible for modifications made by customers to our products in the field, without our supervision, testing or evaluation.

Recycling

The foam pads used in packaging this product are reusable/recyclable. If you would like to help us preserve the environment, dispose of them appropriately or return them to:

Community Playthings,
US Rte. 40, Farmington, PA 15437.

Ordering Parts

To order replacement parts, contact your Customer Center with a description of the part(s) needed and the ID Code from the product.

Use only replacement parts supplied by Community Playthings.

