


---

## Care Instructions

### How to Care for Your Clarus Glassboard

- Dry Erase markers can be wiped off using a simple eraser or dry cloth. Permanent markers may be removed using any standard glass cleaner.
- Periodic cleaning of your Clarus Glassboard may be performed using glass cleaner on the front side of the board only. In most cases, cleaning the back side of the board will not be needed. If cleaning the back side of the board is necessary, use a cloth dampened with a mild soap and water solution.
- Clarus Glassboards recommends Clarus Markers for a premium writing experience. You may use any type of writing instrument, including but not limited to: permanent markers, chalk/grease markers, neon markers or dry erase marker. Please call us if you have any questions, we're here for you! You can also order additional Clarus Markers at [clarus.com/markers](http://clarus.com/markers).



Ready to expand your Clarus collection?  
Visit [clarus.com/buildertool](http://clarus.com/buildertool) to start your next project!

MADE IN THE USA

