



- 1) Level and secure the mounting plate to the junction box with the junction box screws. Also provided are (4) auxilliary fasteners with anchors. Use these in the event the wall is uneven and the fixture does not mount flush.
- 2) Make all electrical connections per local and national codes.
- 3) Secure the lamp plate assembly to the mounting plate with (4) nuts provided.
- 4) Align the threaded studs on the Housing assembly into the slots on the mounting plate. See detail above. Securely fasten with the knurled nuts provided.
- 5) Install lamps and test.

When using electrical equipment, basic safety precautions should always be followed, including the following:

- 1) Read all instructions carefully before installing and save for future use. Make sure all connections are in accordance with the National Electrical Code and local regulations.
- 2) To avoid possible electric shock, be sure the power supply is turned off before servicing or installing the fixture. Service should be performed by qualified personnel.
- 3) These instructions may not cover all details or variations. If additional information is needed, please contact Visa Lighting.

Drawing : 760419XX
Rev: A Sheet1 of 1



1717 West Civic Drive Milwaukee, WI 53209
 414-354-6600
 Design Modification Rights Reserved
 © Visa Lighting 2002

INSTALLATION INSTRUCTIONS:
Fixture family name: Tangle, Sash

Description: Field instructions for mounting fixture to wall

Drawing : 760419XX
 Rev: A

Sheet1 of 1
 Eng: MJH

Date drawn: 12/17/2002