

Background Stand

Parts List




Diagram Number	Da-Lite Number	Description	Quantity Required	List Price Each
1	48289	Small round cap, black	1	\$3.10
2	42080	Crossbar assy. (includes #1 and 4)	1	\$62.00
3	48569	Tripod stand tip	2	\$5.00
4	48286	Large round cap, black	1	\$1.00
5	51037	Roll pin	2	\$0.13
6	58165	Extension tube	2	\$14.10
7	45353	Top cap, black nylon	2	\$1.33
8	46028	Spring for push button assy.	2	\$0.28
9	58237	Push button assy., red	2	\$4.10
10	44703	Screw for top cap	2	\$0.20
11	45115	Bottom tube	2	\$15.60
12	46030	Lift pad for tripod, red	2	\$0.41
13	83062	Tripod assy., black	2	\$22.70
	For complete tripod and tube assy., order as follows: (includes #3 and 5-15)			
	86235	Tripod and tube assy., BGA	2	\$65.60
14	44785	Screw for leg lock	6	\$0.13
15	46928	Leg shoe, black	6	\$0.61
	89586	Packing for BGS	1	\$16.10