












**IMPORTANT NOTICE:
HARDWARE PACKAGE IS ATTACHED
ON THE BOTTOM OF SEAT CUSHION.**

MODEL : B580

(1)x1	(2)x1	(3)x1 (L)x1 (R)
		
TU580-B / Back	TU580-S / Seat	TU058 / Right & Left Arm
(4)x1	(5)x1	(6)x1
		
TU001-Mechanism	TU026-Gas Lift	TU005-Five Star Base
(7)x5	<p>(A)X6  M6X30 Arm Screws</p> <p>(B)X4  M8X22 Mechanism Screws</p> <p>(C)X4  M8X30 Back Bar Screws</p>	
		
TU015-Casters		



Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using. This chair is only intended for sitting. Any other use will void the warranty.

