




Simple

KEILHAUER

1450 Birchmount Road, Toronto, Ontario, Canada M1P 2E3
tel 416 759 5665 fax 416 759 5723 1 800 724 5665
www.keilhauer.com info@keilhauer.com

1. Pneumatic Height Adjustment




Use the small paddle shaped lever on the right side underneath the seat

To raise lift your weight off the seat while pulling the lever up

To lower sit on the seat while pulling the lever up

2. Arm Height Adjustment (optional feature)



Use the button located under the arm cap in the front of the arm

To raise or lower resting your thumb and palm on top of the arm rest, slide your middle fingers to the front of the arms and push the button in – raise or lower the arm rest to the desired position and release the button to lock in position.