

PENDANT INSTALLATION INSTRUCTIONS WITH A DIE CAST HANGER


NOTE: THE JUNCTION BOXES MUST BE SOLIDLY FIXED TO THE CEILING AND ATTACHED TO THE STRUCTURE INSIDE THE CEILING BEFORE PROCEEDING TO THE INSTALLATION.


PART LIST

- A End cap retaining screw
- B End cap
- C Fixture 1
- D Die cast
- E Power cord
- F Ceiling power feed (by others)
- G Canopy
- H $\frac{1}{4}$ 20 threaded stud (by others)
- I Cable mounting nut


- J Aircraft cable
- K Cable grip
- L Cable grip tab
- M Fixture 2
- N Aligner
- O Electrical connectors
- P Quick-wire connectors
- Q Screws
- R Wire nuts









Unscrew retaining screws (A) to remove end cap (B) from fixture (C). Repeat on the both ends of fixture (C).



Slide die cast hangers (D) into fixture (C). Put end caps (B) back in place, secure with retaining screws (A). Repeat on the both ends of fixture (C).



Ensure that the power to the fixture's circuit is turned off. Make a knot on the power cord inside the canopy. Connect the power cord (E) to the ceiling power feed (F).



At all power feed suspension points, place canopy (G) in position on threaded stud (H) and secure with cable mounting nut (I).

FILE NAME:XO.DIE_CAST.INST

LIGHTING

December 15, 2014

I.800.263.AXIS [T] 514.948.6272

[F] 514.948.6271 www.axislighting.com



RISK OF FIRE AND ELECTRICAL SHOCK. FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY IN ACCORDANCE WITH NATIONAL, LOCAL BUILDING AND ELECTRICAL CODES. DISCONNECT POWER AT ELECTRICAL PANEL BEFORE SERVICING.




Page: 1 / 3

Product design and development is an ongoing process at Axis Lighting. We reserve the right to change specifications.


Contact Axis for the latest product information.




PENDANT INSTALLATION INSTRUCTIONS WITH A DIE CAST HANGER




At all suspension points, place canopy (G) in position on threaded stud (H) and secure with cable mounting nut (I).




Push the aircraft cable (J) through the cable grip (K).



For adjustment press tab (L) on grip lock (K) to release or slide cable grip (J).



For a continuous row system - last fixture: With first fixture in place, remove end cap (B) from next fixture (M). Slide die cast hangers (D) on to fixture (M). Put end caps (B) back in place, secure with retaining screws.



Push the aircraft cable (J) through the cable grip (K). For adjustment press tab (L) on grip lock (K) to release or slide cable grip (J). Continue to step (2).

FILE NAME:XO.DIE_CAST.INST

LIGHTING


December 15, 2014

WARNING:





PENDANT INSTALLATION INSTRUCTIONS WITH A DIE CAST HANGER




K


Push the aircraft cable (J) through the cable grip (K). For adjustment press tab (L) on grip lock (K) to release or slide cable grip (J).

For a continuous row system - middle fixture:

With first fixture in place, slide die cast hangers (D) into fixture (M).



Connect the electrical connectors (O) between the fixtures using supplied quick-wire connectors (P).



Connect the fixtures (C) and (M) using the aligner (N) and secure with screws (Q). Install the lamps in the fixtures.

LIGHTING

1.800.263.AXIS



Page: 3 / 3