




LENS REPLACEMENT INSTALLATION INSTRUCTIONS




1 Turn the lens clip (A) to release the lens (B). Pry both sides of the lens (B) away from the fixture (C) at one end.



2 Once freed from the fixture (C), slide lens (B) downwards.



3 To install new lens, starting at one end, slide the lens (B) onto the sides of the fixture (C).



4 Pushing the lens (B) onto the fixture (C). The lens (B) will snap into it's final place. Turn the lens clip (A) to lock the lens (B) in place.