
## Steelcase®

## **Garland - Stacking Bookcase Installation**



If you have a problem, question, or request, call your local dealer, or Steelcase Line 1 at **888.STEELCASE** (888.783.3522) for immediate action by people who want to help you.

(Outside the U.S.A. Canada, Mexico, Puerto Rico, and the U.S. Virgin Islands, call: 1.616.247.2500) Or visit our website: www.steelcase.com

© 2002 Steelcase Inc. Grand Rapids, MI 49501 U.S.A.

Page 1 of 3 Y9501753 Rev. F

Power Driver \
with Phillips tip


1/8" dia.

(3 mm)


Printed in the U.S.A.

## Steelcase

- **1.** Determine locations for modeez screws from chart.
- 2. Drill pilot holes 1/8" (3.1mm) dia. And ½" (12.7mm) deep. Install (4) modeez screws.
- **3.** Remove glides and any other obstructions from bottom of bookcase.



	DIM A	DIM B	DIM C	DIM D
Garland 40-1/4"	9/16"	4-13/16"	13-11/16"	35-1/16"
High Bookcase	(14.8 mm)	(122 mm)	(348 mm)	(890 mm)



## Steelcase BOOKCASE -**4.** Position bookcase on top of lateral file so that modeez screws are located to rear of female 4 modeez fasteners. MODEEZ SCREW **5.** Slide bookcase in direction of arrow until bookcase end panel and end panel of lateral file are in alignment. FEMALE MODEEZ **FASTENER** BOOKCASE END PANEL LATERAL FILE ~ END PANEL

Page 3 of 3 Y9501753 Rev. F