

Operating Instructions ■

Perth® Recliner

September 2011




Figure 1 - Standard Recliner



Figure 2 - Wallsaver Recliner

Standard Recliner

To engage recline, put hands on the arms of the chair and lean back to desired degree of recline (Figure 1). To disengage recline and bring chair back to the upright position, put hands on arms of the chair, lean forward, and use legs to push footrest closed.

Wallsaver Recliner

Wallsaver recliner operates with a side handle release that raises and lowers the footrest (Figure 2). The footrest must be raised with the side handle release before the chair will move into the recline positions.