


Parts Diagram

G2 Tablet Arm

June 2019



".LXX" = Select Laminate

Item	Part Number	Item Description	Qty
1	06.0181.X	Plug, G2 Tablet Arm Support Tube End	2
2	46.3143.X	Stop, 75° Outer Tablet Arm Pivot (RH)	1
	46.3142.X	Stop, 60° Outer Tablet Arm Pivot (LH)	1
3	46.3145.X	Stop, 75° Inner Tablet Arm Pivot (RH)	1
	46.3144.X	Stop, 60° Inner Tablet Arm Pivot (LH)	1
4	12.0671.X	Screw, #12-32 x .50 FL HD ST Torx	8
5	46.3580.BL.X	Assembly, G2 RH / K2 LH Tablet Arm Hinge Slv Pin	1
	46.3581.BL.X	Assembly, G2 LH / K2 RH Tablet Arm Hinge Blk Pin	1
6	TARM	Board, RH Laminated Tablet	1
	TARM	Board, LH Laminated Tablet	1
7	12.0049.X	Screw, #12 x 5/8" Phillips FL HD Tap	6

