



Parts Diagram ■


University™ Seating

Select Swing-Arm Base - UNIVS

June 2018



Un-Notched Floor Flange



Notched Floor Flange

■ University™ Seating - Select Swing-Arm Base - UNIVS

Parts Diagram

.XX = Select Color

"Y" = Slope (0-9)

Item	Part Number	Item Description
1	46.3159.YXX.ASM	Leg Weldment
	46.3160.YXX.ASM	Leg Weldment, 4" Additional
2	46.3162.27.LXXA	Swing Arm Wldmt., 27", Torsion, Torsion Air, Strive, Wave, Dorsal, 1000 Poly, Apply, Doni, Grazie, Left-hand Assembly
	46.3162.27.RXXA	Swing Arm Wldmt., 27", Torsion, Torsion Air, Strive, Wave, Dorsal, 1000 Poly, Apply, Doni, Grazie, Right-hand Assembly
	46.3162.30.LXXA	Swing Arm Wldmt., 30", Torsion, Torsion Air, Strive, Wave, Dorsal, 1000 Poly, Apply, Doni, Grazie, Left-hand Assembly
	46.3162.30.RXXA	Swing Arm Wldmt., 30", Torsion, Torsion Air, Strive, Wave, Dorsal, 1000 Poly, Apply, Doni, Grazie, Right-hand Assembly
3	46.3161.27.LXXA	Swing Arm Wldmt., 27", Piretti 2000 Task, Apply, Doni, Grazie, Left-hand Assembly
	46.3161.27.RXXA	Swing Arm Wldmt., 27", Piretti 2000 Task, Apply, Doni, Grazie, Right-hand Assembly
	46.3161.30.LXXA	Swing Arm Wldmt., 30", Piretti 2000 Task, Apply, Doni, Grazie, Left-hand Assembly
	46.3161.30.RXXA	Swing Arm Wldmt., 30", Piretti 2000 Task, Apply, Doni, Grazie, Right-hand Assembly
4	46.3208.BL.X	Bumper, Leg Weldment/Swing Arm, Rear
5	46.3192.X	Bumper, Leg Weldment/SwingArm, Front
6	53.6421.X	Bushing, Swing Arm
7	46.3634.X	Bolt, 1/2" x 4-1/4" Shoulder
8	46.3154.X	Shroud Support
9	06.4212.X	Bushing, Bottom
10	06.4213.BL.X	Upper Cam
11	06.4215.X	Lower Cam
12	12.0030.X	Washer, 3/4 x 1 1/4", 18 Gauge
13	53.4211.BL.X	Spacer
14	06.0030.X	Plastic Bearing
15	45.4202.X	Compression Spring
16	12.4202.X	Retaining Ring
17	45.0080.C.X	Spring, Swing Arm
18	12.2801.X	Screw, 1/4-15 x 3/4" PPH
19	12.3008.X	Flange Locking Nut, 3/8"-16
20	46.3155.X	Electrical Bracket (used with side infeed only)
21	12.0074.P.X	Screw, 1/4-20 x 5/8" Self-tapping (used with side infeed only)
22	12.0950.X	Clip, Black Flange (used on notched floor flange)
	12.0395.X	Clip, Flange (used on un-notched floor flange)
23	46.3151.XX.X	Base Flange Skirt
24	46.3150.XX.X	Shroud Half, Select Base
25	46.3163.XX.X	Oval Face Plate (used with side infeed only)
26	PC.12.0009.XX.X	Screw, #10-24 x 1/2" Self-tapping
27	46.3166.X	Plastic Side Shield (with opening for swing-arm)
28	46.3166.S.X	Plastic Side Shield (solid for no swing-arm)

