


See-Through Arm Version

If you have a problem, question, or request, call your local dealer, or Steelcase Line 1 at **888.STEELCASE** (888.783.3522) for immediate action by people who want to help you. (Outside the U.S.A., Canada, Mexico, Puerto Rico, and the U.S. Virgin Islands, call: 1.616.247.2500) Or visit our website: [www.steelcase.com](http://www.steelcase.com)

© 2014 Steelcase Inc.  
Grand Rapids, MI 49501  
U.S.A.  
Printed in U.S.A.



## Arm Cap Replacement

**NOTE:** The arm does not have to be removed from the chair to replace the arm caps.

**1.** Remove four (4) screws to remove arm cap and discard.

**2.** Replace with new arm cap and secure with four (4) NEW socket head screws.

