


## Installing Shims to Universal Worksurfaces Mounted to Answer®, Montage®, Tethered or Table Applications

To adjust leg angle, insert shim  
from either side of mounting plate.  
A maximum of 2 shims are allowed  
per mounting plate.



**888.STEELCASE** (888.783.3522)

[www.steelcase.com](http://www.steelcase.com)

© 2019 Steelcase Inc.  
Grand Rapids, MI 49501  
U.S.A.