## HAWORTH<sup>®</sup>




Improv H.E.

#### **Standard Feature**

Seat Height



# Pull lever up. Lift weight out of chair. Sit in chair to lower.



## Standard Feature

Seat Depth



# Pull lever up. Slide seat pan forward or backward.



Note: Not available on stool. For XL, see your facilities manager

### Standard Feature


Tilt Tension




# Rotate clockwise for more tension. Counter-clockwise



#### Standard Feature



#### Pull lever toward seat. Raise or lower back.




#### Optional Feature

Forward Tilt



To activate, pull lever up and lean forward. To release, pull up




recline

#### **Optional Feature**

Back Lock



#### Push lever down to lock back. Pull lever up to unlock.




#### Optional Feature

Lumbar Depth



### Pump lever upward to increase. Hold lever down to release.





Pull up on button. Move up and down to adjust. Release button to lock in position.



No Adjustments



Pull up on button. Move up and down to adjust. Release button to lock in position. Arm Rotation:

Rotate arm cap to reposition.



During keying and mouserelated tasks, no more than 1/3 of the arm, near the elbow, should be supported.



### Arm Height:

Pull button. Move up/down. Release button.

Arm Rotation:





During keying and mouserelated tasks, no more than 1/3 of the arm, near the elbow, should be supported



Arm Width:

Pull lever. Swing in/out. Release lever.

# Ergonomic tips and hints

- Change your posture
  every hour.

  Sit back in your chair to
  contact back support.
- contact back support.

  Align chair to task.

  Adjust arm height to maintain a neutral wrist

posture.

- Feet should be placed flatly on floor or footrest.
- Avoid pressure at back of knee.

www.haworth.com

