

## K-T14420, K-304, K-305, K-306 PURIST<sup>TM</sup> RITE-TEMP<sup>TM</sup> PRESSURE-BALANCING FAUCETS

## **Product Information**

Applicable faucet trim only:			
Bath and shower cross handle* (shown)		K-T14420-3	
Bath and shower lever handle*		K-T14420-4	
Shower cross handle*		K-T14421-3	
Shower lever handle*	K-T14421-4		
Non-diverter valve cross handle*		K-T14423-3	
Non-diverter valve lever handle*		K-T14423-4	
Shower head, arm and flange		K-14424	
35° Bath Spout		K-14426	
90° Bath Spout		K-14427	
*Rite-Temp valve must be ordered to complete faucet.			
Applicable Rite-Temp valve only:			
Rite-Temp valve without stops	K-304-K	not shown**	
Rite-Temp valve with stops	K-304-KS	not shown**	
Rite-Temp valve with CPVC female stops	K-304-KP	not shown**	
Rite-Temp valve without stops	K-305-K	not shown**	

Rite-Temp valve with stops	K-305-KS	not shown**
HiFlow Rite-Temp valve with integral stops	K-306-KS	not shown**
HiFlow Rite-Temp thin wall installation kit	88526	not shown**

\*\*Required for configuration illustrated.

Cross and lever handles are ADA compliant




WARNING: Risk of damage to the K-306-KS valve assembly. When using the K-306-KS valve in a fiberglass or acrylic installation, use the thin wall installation kit (88526).

## Installation Notes

Avoid cross-flow conditions. Do not install shut-off device on either valve outlet.

Cap shower outlet if deck-mount spout, diverter, or handshower is connected to spout outlet.

Install straight pipe or tube drop of 7" (17.8cm) to 18" (45.7cm) with single elbow between valve and wall-mount



K-T14420, K-304, K-305, K-306 Purist™ Faucets 1015599-1-A

18

