KOHLER Roughing-In

K-7341, K-7342 HIRISE™ KITCHEN SINK FAUCET

Product Information

Installation Notes

Install this product according to the installation guide.

Applicable products:	
Kitchen sink faucet with 10" (25.6 cm) swing spout – lever handles	K-7341-4
Entertainment sink faucet with 7" (17.8 cm) swing spout – level handles	K-7342-4
Lever handles comply with the actuation force Accessibility Guidelines of the Americans with Disabilities Act.	ADA



