

Priority

Hinge Adjustment

Tools Required

- Phillips Screwdriver

Installation

1. Side Adjustment:

Turn front screw clockwise to increase door overlay, counterclockwise to decrease overlay. (Figure A).

2. Depth Adjustment:

Loosen back screw. Adjust door to desired position and tighten screw. (Figure B).

3. Height Adjustment:

Loosen screws on the mounting plate. Adjust door to desired position and tighten screws. (Figure C).

4. Door Removal and Installation:

Release lever under the hinge arm, pull to remove.

To re-install, place the hinge on the mounting plate and push the rear of the hinge with finger pressure. The snap sound confirms a secure attachment. (Figure D).

Figure A




Figure B




Figure C




Figure D

