


# Assembly Instructions ■

LED Task Light

May 2018



Detail A




Figure 1





Figure 2



Detail B




Figure 3

## Screw Mounted Clip Installation

1. Two bracket clips and two screws are included with light (Detail A).
2. Center and evenly space clips across your fixture. Ensure both clips are oriented in the same direction and screw bracket clips to fixture in desired location (Figure 1).
3. To install light, raise up to clips and align the channel on the back of fixture with clips. Snap into place (Figure 2 & Detail B).
4. Plug DC cord to the on/off/dimmer pack end of fixture and route to power supply (Figure 3).
5. Place power supply on any horizontal surface, allowing the plug to be inserted into 120V AC, 60Hz, grounded outlet (Figure 3).



Assemble units as described herein only. To do otherwise may result in instability. All screws, nuts and bolts must be tightened securely and must be checked periodically after assembly. Failure to assemble properly, or to secure parts may result in assembly failure and personal injury.

# LED Task Light

## Assembly Instructions



Assemble units as described herein only. To do otherwise may result in instability. All screws, nuts and bolts must be tightened securely and must be checked periodically after assembly. Failure to assemble properly, or to secure parts may result in assembly failure and personal injury.

### Standard Magnetic Mount

**Caution:** Magnetic field present in magnetic mount fixture.

1. For direct mounting to metal shelving or overheads, attach magnetic clips to the back surface of the light fixture housing. Use one magnetic clip on each end of the light fixture (Figure 4).
2. Locate fixture to the desired position on metal shelf or overhead (Figure 4) and set in place (Figure 5).
3. Plug DC cord to the on/off/dimmer pack end of fixture and route to power supply (Figure 3).
4. Place power supply on any horizontal surface, allowing the plug to be inserted into 120V AC, 60Hz, grounded outlet (Figure 3).

### Connecting Multiple Fixtures

1. Route interconnect cord from one end of a light fixture to the end of an adjacent light fixture (Figure 6). The maximum distance between the interconnected fixtures is approximately 18", determined by the length of the interconnect cord provided, excluding the connectors.
2. Place power supply on any horizontal surface, allowing the plug to be inserted into 120V AC, 60Hz, grounded outlet (Figure 3).
3. Route the low power DC cord from power supply to the on/off/dimmer pack end of the fixture (Figure 3).

**Note:** All fixtures connected together are controlled by the starter fixture's on/off/dimmer pack. Route cords as to not kink or pinch, which may cause damage to the cord. When connecting more than one fixture, be sure to follow interlinking combination table for optimal performance. Cannot interconnect with any other product family.

### Dimming Operation

1. Touch and hold your finger on the on/off/dimmer pack touch pad switch. The fixture will brighten and then dim. Release the touch pad when preferred level of brightness is obtained. Each time the fixture is turned on it will return to the level of brightness that was set by the user. To reset the brightness to a different light level simply touch and hold the touch pad.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the light unit, Increase the separation between the equipment and light unit, Connect the equipment into an output on a circuit different from that to which the light unit is connected, or consult the dealer or an experienced radio/TV technician for help.




Figure 4




Figure 5




Figure 6