Single-Circuit T~trak™ Adapter With Compact Fluorescent Ballast

700TTCHEDCF

1.2



GENERAL PRODUCT INFORMATION:




This product is suitable for indoor dry locations only.

This product is intended for use only with Tech Lighting Single-Circuit $T\sim trak^{\mathsf{TM}}$ system.




Install the Compact Fluorescent Adapter



NOTE: Turn the power to Single-Circuit T~trak off before installing the compact fluorescent adapter.

- Install the compact fluorescent adapter over the Single-Circuit T~trak.
- 2 Line up the PowerJack cap with the compact fluorescent adapter and screw them together. Make sure not to cross thread.



NOTE: Use **MAX 35** watt fluorescent fixture with the Single-Circuit T~trak compact fluorescent adapter.

- Line up and mate the socket contacts with the compact fluorescent adapter contacts.
- 4 Slide the PowerJack housing up and tighten it to the compact fluorescent adapter.

NOTE: In case of cross threading, unscrew the PowerJack housing from the compact fluorscent adapter and repeat steps 1 and 2.

SAVE THESE INSTRUCTIONS!



a brand of **TECH** LIGHTING

7400 Linder Ave. Skokie, IL 60077 847.410.4400

www.ttraklighting.com