A chair sized for everybody

DESCRIPTION		ADJUSTMENT RANGES *		
		Arm Height	Seat Height	Seat Depth
		IN	IN	IN
		mm	mm	mm
0	3021-3 Scale 1 : Multi-tilter Narrow seat width, shallow seat depth. Special height reduced			
	4" pneumatic lift standard with seat depth adjustment (MD slider). Seat and back tilt simultaneously at the same ratio and can be locked in	6.6 - 8.9	14.5 - 18.5	16.5 - 19.0
	an infinite number of positions. Independent back angle adjustment and forward seat tilt adjustments. Back/lumbar height adjustment. Height and width adjustable "T" shaped polyurethane arms. Waterfall seat front.	167 - 227	370 - 474	418 - 482
1	3022-3 Scale 2 : Multi-tilter Standard seat width and seat depth. 4" pneumatic lift standard with seat depth adjustment (MD slider). Seat and back tilt simultaneously	8.3 - 10.8	15.5 - 19.5	17.2 - 19.7
本	at the same ratio and can be locked in an infinite number of positions. Independent back angle adjustment and forward seat tilt adjustments. Back/lumbar height adjustment. Height and width adjustable "T" shaped polyurethane arms. Waterfall seat front.	211 - 274	395 - 497	436 - 500
T	3023-3 Scale 3: Multi-tilter Generous seat width and seat depth. 5" pneumatic lift standard with	05.400	47.0.00.0	40.4 04.0
A	seat depth adjustment (MD slider). Seat and back tilt simultaneously at the same ratio and can be locked in an infinite number of positions. Independent back angle adjustment and forward seat tilt adjustments.	8.5 - 10.9 215 - 278	17.0 - 22.0 433 - 558	19.1 - 21.6 487 - 548
1,	Back/lumbar height adjustment. Height and width adjustable "T" shaped polyurethane arms. Waterfall seat front.	210 - 270	433 - 330	407 - 340

<sup>\*</sup> Obtained using the BIFMA Chair Measuring Device (CMD)® BIFMA/CMD-1 and the Universal Measurment Procedure®



Global - Canada 560 Supertest Road Downsview Ontario Canada M3J 2M6 Tel (416) 661-3660 (800) 668-5870 Customer Service: Fax (800) 361-3182 Government Customer Service: Fax (416) 739-6319

Global - U.S.A. 17 West Stow Road P.O. Box 562 Marlton New Jersey U.S.A. 08053 Tel (856) 596-3390 (800) 220-1900 Fax (856) 596-5684

Global - International 560 Supertest Road Downsview Ontario Canada M3J 2M6 Tel (416) 661-3660 (800) 668-5870 Fax (416) 667-1821

GGI Office Furniture (UK) Ltd. Global Way Darwen Lancashire UK BB3 ORW Tel +44(0) 1254 778500 Fax +44(0) 1254 778519

Visit us on the World Wide Web at www.globaltotaloffice.com



# A chair for EVERYbody


The Scale 1,2,3 series was designed to accommodate as many people sizes as possible. Ergonomic seating solutions are not just about dimensions, but if some chair features are not the right size, users may never get the proper support they need as they change postures. In addition to the scaled proportions of this series, each chair has multiple adjustable features that allow a user to customize the fit of the chair for their own body and preferred postures.



Scale 1
Designed to accommodate smaller individuals,
Scale 1 measurements have been adjusted to
a smaller scale including smaller seat and back
cushions, lower seat height and arm height ranges
and arms that adjust closer together.



Designed to fit most people, Scale 2 dimensions and adjustment ranges make this the seating solution for many people.



Designed to be more generous in its proportions to accommodate larger people, Scale 3 has larger seat and back cushions, higher seat height and arm height ranges, and more space between the arms.

#### Wide choice of upholstery fabrics

Hundreds of fabric and color choices all intended for heavy duty commercial applications.

#### Back/Lumbar Height Adjustment

Allows user to raise or lower backrest to position the lumbar support in the small of their back for optimum comfort and support. Reduces likelihood of back pain.

#### Infinite Angle Chair Tilt-lock

Allows user to lock the tilting action of the chair in any position throughout the tilt range or leave the tilt action in free float. Accommodates user's preferred working postures and encourages comfortable and supportive working positions.

#### Pneumatic Seat Height Adjustment

Scale 1,2 and 3 have different seat height adjustment ranges to accommodate people with different lower leg lengths. Allows user to adjust seat height so that their feet are flat on the floor without pressure under their thighs. Helps encourage blood flow.

#### Forward Seat Angle Adjustment / Lock

Allows user to tilt the seat forward changing the angle of their thighs in relation to the floor. Helps keep the body angle open thus reducing disc pressure during forward leaning tasks.

#### Back Angle Adjustment

Allows user to adjust the angle of the back in relation to their thighs for full supportive back contact. Helps reduce disc pressure and relaxes back muscles.

#### **Dual Wheel Casters**

Roll smoothly and easily on any surface. Scale 1,2 and 3 chairs come standard with carpet casters. Special casters are available for hard surface flooring.

#### Scale Armcap

Broad, concave, soft, warm to the touch and extremely rugged. Made from durable molded polyurethane with a textured surface.

#### Arm Height Adjustment

Scale 1,2 and 3 have different arm height ranges to accommodate different upper arm lengths. Allows user to raise or lower armrests to support their forearms. Reduces muscular effort in neck and shoulders, minimizing the

# Arm Width Adjustment

Allows user to properly position the arms to provide comfortable, effective support. Reduces muscular effort in the neck and shoulders minimizing the risk of pain.

#### Seat Depth Adjustment

Scale 1, 2 and 3 chairs have different seat sizes and seat depth adjustment ranges to accommodate variation in thigh length. Allows user to easily slide the seat to change the depth for the length of their thighs. Helps maintain proper back support while avoiding pressure at the back of their knees.

### Tension Adjustment

Allows user to increase or decrease tilt tension to match their body weight so they can tilt freely in their chair. Avoids heavy pushing thus reducing muscle fatique.

## Arched Spider Base

Reflects the curved shape of the Scale series. Made from extremely durable fiberglass impregnated nylon and will provide many, many years of trouble free service.









#### **Arm Width Adjustment**

Swing the lever to disengage the lock, slide the arm to the desired position, then snap the lever back into position. This standard feature provides up to 2 inches of width adjustment on each side of the seat.



#### **Arm Height Adjustment**

Squeeze the trigger on the side of the arm, raise or lower the arm to the desired height and release. This standard feature provides effective arm support for a variety of tasks.



# Seat Depth Adjustment (Seat Slider)

Pull up on the control bar under the seat and slide your body and the seat forwards or backwards. This standard feature ensures that the seat depth can be easily changed to suit user thigh length.