


# Installation Instructions


## Joint System: 806 - A01/ A02

**Note: Verify that the structural gap is in conformance with submittal data before beginning installation. If this is a Fire Rated Assembly, install the fire barrier before the Architectural Joint System. Refer to the fire barrier instructions for specific system installation.**


**Fig 1**




**Fig 2**



**FIG. 3 (806-A01 COMPLETE INSTALLATION)**



**FIG. 3a (806-A02 COMPLETE INSTALLATION)**



1. Install the architectural joint system on a level finished floor. This may require adding leveling compound on top of the substrate to provide a smooth mounting surface.

### See Figure 1

2. Cut the aluminum plates to the desired length. Slide the pivoting half of the hinge plate into the anchored half of the hinge plate.
3. Place the plate assembly over the structural gap.
  - 3a. For floor to floor (A01) condition, plate should be centered over the structural gap keeping the predrilled mounting holes on one side.
  - 3b. For floor to wall (A02) condition, short leg (predrilled hole side) should be placed firmly against the finished wall. Align level with the finished floor. See Figure 1a.
4. Mark the pre-drilled hole locations on the substrate.
5. Remove the plate assembly.

### Figure 2

6. Drill all marked holes on the substrate using a 1/4" (6 mm) drill bit and drill 2 1/4" (58mm) deep. Insert concrete sleeve anchors.
7. Return the plates into position over the drilled hole locations and secure in place with one flat head screw for each anchor.

Figure 3 & 3a.

8. Clean the exposed surfaces with a non-solvent cleaner, such as 409, as required.

IPC.917/Rev.1

### Installation Questions?

Contact our Installation Hotline 866.EZINPRO  
For Sales & Customer Service call 800.222.5556

**INPRO CORPORATION.**  
Interior and Exterior Architectural Products