


1. Examine goods to assure quantity and quality is as ordered. Lay out the work to be completed, including all parts, along the base of the wall. The parts will include those supplied by **walltalkers®** and those the installer must supply. **walltalkers** supplies the extruded aluminum tray, steel mounting clips, end caps, and splice brackets in the quantities ordered. The installer must supply the hardware, **#10 X 1½" truss head sheet metal screws** for most applications and **1/8" diameter X 3/8" grip aluminum pop rivets**. **Masonry anchors** and manufacturer specified screws must be used for concrete or block wall installations. One screw and/or anchor is required for each mounting clip; clips are installed 16" on center.
2. Determine the finished length of the marker tray, with or without ends. If using ends, deduct exposed portion of ends from overall length of tray. For wall to wall applications, end caps are not necessary. Using a **fine tooth carbide tip blade** on a radial arm or miter saw, cut a small portion of one end of the aluminum tray at a 90° angle, assuring a square end. From the cut end, measure and cut the opposite end in the same manner.
3. Apply a small bead of construction adhesive to the end cap tab. Insert the end cap tab into the corresponding open end of the marker tray. Follow the same steps for the other end cap.
4. Determine the finished height, top of the tray, and side-to-side location for the tray on the wall. Snap a level chalk line 3/32" below the finished height. Line up the top of the steel

mounting clips, i.e. the flat beveled side, to the chalk line. Mount using condition appropriate hardware, as noted in step 1, 16" on center into the wall studs, wood blocking, or masonry. **Toggle bolts** or similar hardware may be substituted at locations where studs cannot be located. Install clips 4" in from each outside edge of the end caps, since ends will not snap over clips; center the screw hole at that location. Snap tray cover over the clips, this may require two installers for longer lengths. Hook the top back edge over the tops of the clips and apply downward pressure to lock the tray in place.

5. If a splice is required, follow the detail below. The spliced pieces of aluminum, like the ends, require clean right angle cuts for the joint to have a good appearance. Mount a steel clip on the wall at the splice location, 1/2 of the clip should line up inside each piece of tray. If also installing aluminum trim, use a 4" piece of trim (splice bracket), mount inside the tray. If no aluminum trim is available, any piece of 1½" X 4" piece of aluminum or steel will work. Clamp the splice bracket inside one of the pieces of tray, about half way between the face and bottom edge. One inch in on the tray about half way between the face side and the bottom, drill an 1/8" hole. Drill through both tray and bracket. Insert the 1/8" aluminum pop rivet and grip tight. Repeat for attaching the second piece of tray, making sure both pieces are tight together.



aluminum tray installation instructions

www.walltalkers.com

walltalkers

a division of **RJF International Corporation**

3875 Embassy Parkway
Fairlawn, OH 44333

PH: 800.820.9255 • Fax: 330.668.7703

7075ATY2111 4/05